



ROCKER GUARDS WITH STEP

(2021-2025+ BRONCO - 2 DOOR)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Rocker Step
- (1) RH Rocker Step
- (1) Front LH Mounting Bracket (-DF)
- (1) Rear LH Mounting Bracket (-DR)
- (1) Front RH Mounting Bracket (-PF)
- (1) Rear RH Mounting Bracket (-PR)
- (8) M10x1.50 x 30mm Bolts
- (8) M10 Lock Washers
- (8) M10 Flat Washers
- (8) M8x1.25 x 25mm Combo Bolts

TOOLS REQUIRED


13mm, 16mm Sockets
Ratchet

SKU # FB12817

STEP 1

Install (1) LH front mounting bracket to the threaded holes in the vehicle rocker panel using (2) M10x1.50 x 30mm bolts, (2) M10 lock washers, and (2) M10 flat washers. Do not fully tighten.

Note: Mounting bracket is labeled “-DF”.

STEP 2

Install (1) LH rear mounting bracket to the threaded holes in the vehicle rocker panel using (2) M10x1.50 x 30mm bolts, (2) M10 lock washers, and (2) M10 flat washers. Do not fully tighten.

Note: Mounting bracket is labeled “-DR”.

STEP 3

Install the rocker armor to the mounting brackets using (6) M8 x 25mm bolts into the threaded inserts in the rocker armor. Tighten until secure.

Note: The rocker armor is dedicated to each side, note the locations of the threaded inserts.

STEP 4

Fully tighten the mounting brackets to the vehicle. Repeat steps 1-3 to the opposite side of the vehicle.

Installation is now complete.