



CARGO TONNEAU COVER

(2021-2025+ BRONCO - 4 DOOR)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Tonneau Cover
(8) M8x1.25 x 30mm Torx Bolts

TOOLS REQUIRED

T-45 Torx Socket
Ratchet
Isopropyl Alcohol
Microfiber Cloth

STEP 1



Place the tonneau cover under the sun for 30 min - 1 hour. This will allow the material to become more flexible to ease the installation process.

Remove the OEM vehicle top from the vehicle following the OEM removal procedure. Clean the vehicle side rails using isopropyl alcohol and a microfiber cloth, then allow to fully dry.

STEP 2



Loosely thread the tonneau cover into each side of the vehicle using the (8) T-45 Torx bolts. Begin at the rear of the vehicle, and work forwards. Do not fully tighten any hardware.


Note: The tonneau cover is intended to be a tight fit and will require moderate pulling/stretching to meet each bolt hole. After the initial installation, the tonneau will become easier to install over time.

STEP 3



With all bolts started, peel the tape backing from the Velcro, and adhere the Velcro strip to the vehicle body on both sides.

STEP 4



Using the zippers attached to the rear of the tonneau cover, zip the tonneau cover together around the vehicle roll bars.



STEP 5

Press the Velcro at the front of the tonneau cover to the vehicle rear seats. The Velcro will attach to the vehicle rear seat material.



STEP 6

Fully tighten the (8) T-45 Torx bolts to secure the sides of the tonneau cover.

STEP 7



Close the vehicle taiglate. Route the (4) rear tonneau cover straps over the top of the tailgate. Clip the strap hooks to the bottom lip of the tailgate. Tighten the straps evenly to add tension to the tonneau cover. Fit the strap after tightening into the pre-installed elastic strap holder.

Note: Ensure to route the straps away from any moving components and wiring.

STEP 8



Installation is now complete.